


SIERRA

ASSEMBLY INSTRUCTIONS



- PARTS LIST

LABEL	PICTURE	DESCRIPTION	QTY
А		HEADBOARD	1
В		FOOTBOARD	1
С		SIDERAIL LEFT AND RIGHT	2
D		MIDDLE RAIL	1
Е		CENTER LEGS	2
F		SLAT FRAME (14 wood bar)	2

ASSEMBLY STEPS STEP 1 **(G**)

HARDWARE -

LABEL	PICTURE	DESCRIPTION	QTY
G		SCREW M6x10	8
Н		WRENCH M5x60	1
L	C imming-	SCREW M4x30	14

BEFORE BEGINNING ASSEMBLY:




Read instructions cover to cover

Have two adults on hand for assembly

Do NOT assemble on flooring or carpet. Assemble on a clean nonmarring surface (ex: packing foam)



Save all packaging until assembly is completed



CARE & MAINTENANCE



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish



Dust and wipe up spills using a clean, non-colored, lint-free cloth.



Stains may be removed with a mild soap solution and a damp cloth.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside, for indoor use only.

"Need a part? Call TOV at 516-888-3355 or email service@tovfurniture.com"