












SARENGETI OUTDOOR  
PENDANT LAMP

# SARENGETI OUTDOOR PENDANT LAMP ASSEMBLY INSTRUCTIONS



## Part List and Hardware List

PART	DESCRIPTION	PICTURE	QUANTITY
A	CANOPY		1X
B	MOUNTING PLATE		1X
C	SIDE SCREW		2X
D	PLASTIC CEILING MOUNTS		2X
E	SCREW		2X
F	PLASTIC CONNECTORS		3X
G	CORD GRIP		1X
H	SHADE		1X

### PREPARATION


Before beginning assembly of product, make sure all parts are present.

Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

1




Ⓝ Neutral (White)  
ⓔ Earth (Yellow/Green)  
Ⓛ Live (Black)

(1) Secure the mounting plate (B) with screw (E) in the Plastic Ceiling Mounts (D).

(2) After securing the mounting plate, Connect the two power wires coming out from the ceiling to the White Plastic Connector (F).

### Step 1

2



(3) Tighten the canopy (A) with side Screw (C) to the mounting plate (B) and tighten the screw on the plastic cord grip (G).

(4) Secure the Light Bulb / 1 x E26 into the Lamp Holder.

## Step 2