




Tabby Glossy Lacquer Dining Table
TOV-D44205

TABBY


ASSEMBLY INSTRUCTIONS



PARTS LIST

LABEL	PICTURE	DESCRIPTION	QTY
①		Tabletop	1
②		Leg	4

HARDWARE

LABEL	PICTURE	DESCRIPTION	QTY
A		Allen Key M5	1
B		Bolt M8*40	16
C		Washer M8*22	16
D		Spring M8	16

BEFORE BEGINNING ASSEMBLY:



Read instructions cover to cover



Have two adults on hand for assembly




Do NOT assemble on flooring or carpet. Assemble on a clean non-marring surface (ex: packing foam)




Save all packaging until assembly is completed

ASSEMBLY STEPS



- › **The four legs are in a separate box as shown.**
- › **Open to take the four legs.**

STEP 2



CARE & MAINTENANCE



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Dust and pick up spills using a clean, non-colored, lint-free cloth.



Stains may be removed with mild soap solution and a damp cloth.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside, for indoor use only.