


YARETZI PENDANT LAMP

TOV-G18409











TOV

YARETZI

ASSEMBLY INSTRUCTIONS




PARTS LIST & HARDWARE LIST

LABEL	DESCRIPTIONS	PICTURE	QTY
A	CANOPY		1X
B	MOUNTING PLATE		1X
C	SIDE SCREW		2X
D	PLASTIC CEILING MOUNTS		2X
E	SCREW		2X
F	UPPER LAMP PART		1X
G	LOWER LAMP PART		1X
H	SOCKET		1X
I	SHADE		1X
J	PLASTIC RING		1X


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 10 minutes.



Step 1

2



Step 2

Fix the upper lamp part (F) on the lower lamp part (G) by rotating clockwise to tighten.

Fix the lower lamp part (G) on the socket (H) by rotating clockwise to tighten.

Unscrew the plastic ring (J) from bulb holder socket (H).

Put the lamp Shade (I) on bulb holder socket (H) and fix with the Help of plastic ring (J) by rotating clockwise to tighten.

Slightly move the shade to check if it has been adequately tightened. If it feels loose, screw in the plastic ring (J) until it is tightly screwed.

CARE & MAINTENANCE

1. Do not use acids or alkaline cleaning agents.
2. Sharp objects will damage and scratch the surface.
3. Wipe the surface with a soft, damp cloth.
4. Please make sure that you have all parts indicated before you begin assembly of this item
5. This item should be assembled on a soft surface to prevent scratching the finish during assembly
6. This item may require periodic tightening



Save all packaging until assembly is completed

Need a part? Call TOV at 516-888-3355 or email service@tovfurniture.com