




Dente Dining Chair

DENTE





ASSEMBLY INSTRUCTIONS



PARTS LIST

LABEL	PICTURE	DESCRIPTION	QTY
A		Chair Body	1
B		Leg	4

HARDWARE

LABEL	PICTURE	DESCRIPTION	QTY
D		Metal Gasket	12
E		Spring Washer	12
F		Screw(M6*30)	12
G		Wrench	1

BEFORE BEGINNING ASSEMBLY:



Read instructions cover to cover



Have two adults on hand for assembly



Do NOT assemble on flooring or carpet. Assemble on a clean non-marring surface (ex: packing foam)




Save all packaging until assembly is completed

Need a part? Call TOV at 516-888-3355 or email service@tovfurniture.com


ASSEMBLY STEPS

STEP 1




› Open to remove the four legs and hardware.

STEP 2



- › Position chair bottom up as shown.
- › Use provided hardware to attach the legs.

STEP3



Carefully turn over the chair.

Assembly is completed.

CARE & MAINTENANCE



Do not put hot items directly on furniture surface.



Do not clean furniture with harsh cleansers or polish.



Dust and pick up spills using a clean, non-colored, lint-free cloth.



Stains may be removed with a mild soap solution and a damp cloth.



Do not place furniture under direct sunlight.



Do not place furniture near heating or cooling vents.



Do not write on furniture without a padded barrier to protect the surface.



Do not place furniture outside, for indoor use only.