







TOV



Betty
Dining Chair

DON'T BE BORING.

Hardware and Components

	A X 4 pcs
	B X 8 pcs
	C X 8 pcs
	D X 8 pcs (6mm x 65mm)
	E X 1 pc Ball-End Allen Wrench - 6mm

Step 1


Open box of hardware and legs.

This hardware box will be a smaller box inside of the main box. Look for the red streamer.



Step 2


A. Tip the chair over, position 1 leg (part A1) in #A1 wooden corner. Insert 2 bolts with washers(parts B.C.D) into the corner to connect the Leg. Use Ball-end Wrench (part E) to tighten the bolts clockwise, do not fully tighten until the last step. Repeat the same steps for the other 3 legs.



Step 3

A. Tip chair back over. Adjust the angle of the legs until they are even, fully tighten the bolts(D) .

B. Complete!



Stuck?
Contact our team @ 516-888-3355
Scan for product care!



TOV



Follow us!

Show your new purchase some love by tagging it on our Instagram!

-  @tovfurniture
-  516-888-3355
-  hello@tovfurniture.com
-  www.tovfurniture.com

If the future is female—your furniture should be, too. No mahogany in sight. Sexy settees shaped like lips. Price points for any budget. At TOV, we do things differently.