

TOV



Follow us!

Show your new purchase some love by tagging it on our Instagram!

 @tovfurniture


 516-888-3355

 hello@tovfurniture.com

 www.tovfurniture.com

If the future is female—your furniture should be, too. No mahogany in sight. Sexy settees shaped like lips. Price points for any budget. At TOV, we do things differently.


TOV




Barbara Cream Round Dining Table

DON'T BE BORING

Hardware and Components



..... **A** Top x 1 Pcs



..... **B** Leg A1 x 1 Pcs
Leg B1 x 1 Pcs
Leg C1 x 1 Pcs
Leg D1 x 1 Pcs



..... **C** Allen Bolt x 12 Pcs



..... **D** Washer x 12 Pcs



..... **E** Allen-Key x 1 Pcs

Step 1


Open box of hardware and legs.

This hardware box will be a smaller box inside of the main box. Look for the red streamer.



Step 2

1. Open the product from the packet and unwrap the foam sheet wrapping.
2. Remove all the hardware from the packet.
3. Place the dining table top (A) upside down on a carpet or padded area to avoid scratching.
4. Please place the legs on the place identified as A1, B1, C1 & D1.
5. Match the label on legs with the label on the top. (A1 with A1, B1 with B1, C1 with C1 & D1 with D1)
6. Screw All the Allen Key Bolt (C) using the Allen key (E).
7. Flip back the dining table to the right position.



Stuck?

Contact our team @ 516-888-3355

Scan for product care!

